## UV lacquered finished-Cleaning and Maintenance

**WOCA lacquer soap** is suitable for the cleaning of all vinyl, laminated, lacquered or painted surfaces. Vinyl- and Lacquer Soap does not build up soap film, and therefore it is very suitable for surfaces requiring frequent cleaning.

## **Application**

- 1) Mix 125 ml WOCA Vinyl- and Lacquer Soap with 5 litres of water for regular cleaning.
- 2) Clean the floor with a well wrung mop/cloth. We recommend working with two buckets, one with clean water in which you wring the mop and one with soap solution.
- 3) It is important not to leave any water on the surface after cleaning.
- 4) Extremely dirty floors/difficult spots can be removed with Wood Cleaner or Spot Remover.

#### Lacquer Care for ongoing maintenance of Lacquered finished floor

**WOCA Vinyl- and Lacquer Care** is suitable for PVC, laminated and lacquered surfaces. WOCA Vinyl- and Lacquer Care strengthens the surface as it protects against wear and tear and scratches and in that way, it prolongs the life of the lacquered surface. WOCA Vinyl- and Lacquer Care is self-removable by next application and therefore, it does not build up a thick layer on the surface. Apply as needed.

### **Application**

- 1) It is recommended to have cleaned the floor with a Wood Cleaner prior to the application of Lacquer Care. The floor must be absolutely dry before application of Lacquer Care.
- 2) Shake the bottle well before use and have two buckets ready.
- 3) In one bucket pour the Lacquer Care in straight (do not dilute with water).
- 4) Fill the second bucket with clean rinsing water.
- 5) At first, dip the mop into the Lacquer Care and wring it out completely. Work the mop along the length of the boards applying a thin coat. Work in small manageable sections. Do not continue application of Lacquer Care when the floor has started to dry. Note: Rinse mop in clean water and wring out well. If the mop head is looking dirty, continue step 5 until the entire floor is coated.
- 6) Leave surface to dry for approximately 30 minutes or until fully dry.

# Protection after installation and maintenance.

Every French Oak floor is an investment that can last a lifetime; it's always worth making the effort to:

1) Place a good rug at the entrance and near any bifold or sliding doors.
2) Immediately remove any type of sand or gravel.
3) Use protective pads under furniture legs.
4) Avoid walking with sharp heels.
5) Dry any liquid splashes immediately.
6) Protect from extreme sun and intensive UV light.